



## Outdoor Furniture Assembly Instructions for Picnic Tables

### Tools Required:

- Shifting wrench to tighten the nuts
- Drill, preferably cordless for tightening the screws in the internal stays
- Hammer to knock through the bolts

### Instructions:

1. Lay the table top upside down on cardboard or grass.
2. To attach the legs - fit the bolts supplied through the legs at each end from the outside to the inside of the table top. Then apply the washers and nuts and tighten to 90%.
3. To attach the seats
  - a) Fit the two cross bars to each of the legs and insert the bolts from the outside. Place the nuts and two washers on each bolt on the inside and tighten to 90%.
  - b) Place the bolts through the seat frame and through the cross beams and tighten to 90%. (This is easier to do with a second person to hold everything together)
  - c) To fit the central stays - position them from the centre of the table top to the cross beams and then insert the screws. Avoid pushing legs outwards, pull slightly inwards if possible.
4. Turn the table over and level it by lifting and dropping each side.
5. Now tighten all the bolts.
6. Finally screw the four hexagon headed locking screws in place.
7. Table complete!

### Tip:

When laying the table top on the ground, make sure there are no stones or other hard objects there that could scratch the top.

