

Plastipole™ - Spigot Model - Concrete In

ASSEMBLY INSTRUCTIONS

PRODUCT CODE: PPSL

! For the SlamLock system to work correctly, it is critical that the PlastiPole is installed at the correct height (see Figure 1).



! The MGB* handle must not rest against the Pawl Release Trigger (see Figure 2). Do not hang the PlastiPole off the MGB during installation.

TOOLS REQUIRED

- Hand auger
- 1 x bag quick set concrete
- 3 metres of wire or rope
- Access to water
- 1 x MGB (Mobile Garbage Bin)
- Cutting saw

DEPTH CHART			
BIN SIZE	SULO	NYLEX	MASTEC
120L	615	615	615
140L	600	600	600
240L	480	480	480

 **Be sure to recycle your off-cut**



Step 1 Dig the hole

Dig a hole using hand auger to correct depth. Refer to Depth Chart.

Step 2 Install the PlastiPole

Once the desired depth is reached, tie the PlastiPole to the MGB* as it would be in the “locked” position, using either wire or rope.

Step 3 Concrete In

Once the correct position is finalised, pour quick set concrete and water into hole and allow to set. Once the concrete has set, the wire or rope can then be removed and your PlastiPole has been successfully installed.

*for best results, use Integrated Recycling's TriLobe Key - Part# PP-TK

CUTTING TIPS

The material can be cut using the same equipment used for handling timber components. Tools must be sharp and eye and hearing protection must be worn. Cutting is best done with a circular saw using a blade with as few teeth per inch as is available. A handsaw can also be used.

WE ARE HERE TO HELP

If you need to know about IR's range of recycled plastic products, please call our knowledgeable staff on 1300 729 253 or email info@integratedrecycling.com.au